

Technical details

5 | canister

order No. 30582



Shadow remover

Area of application

Suitable for interior and exterior graffiti removal. Specially designed for removing old, stubborn residue from absorbent and porous surfaces after using SC GEL or SC FLÜSSIG. SC SCHATTEN can be used without interim cleaning and after applying other products in the SC anti-graffiti







Application

Apply concentrated SC SCHATTEN evenly and leave to work under continuous observation. Monitor the dissolving process. The cleaner works extremely quickly! The effect can be improved by using suitable mechanical systems. Remove dissolved residue immediately and rinse thoroughly with fresh water. Repeat this process until residue has completely disappeared. Dry sensitive surfaces such as paint with an absorbent cloth or similar to prevent shadows caused by the cleaning solution. Work steps can be repeated until the desired result is achieved.

Shadow remover: After using the graffiti remover, apply to the damp surface and leave to work. Rinse thoroughly with water. Dry sensitive surfaces (such as paint) with an absorbent cloth to prevent shadows from forming caused by the cleaning solution.

Caution: SC SCHATTEN is extremely strong and works quickly! Neutralise regularly with water if required to avoid damage to surfaces!

Product characteristics

- NMP-/NEP-free
- Free from orange terpene (significantly reduces allergy risk)
- Suitable for use together with other graffiti removers in the SC anti-graffiti range
- Powerful dissolving capability
- Consumption approx. 150 ml/m²
- Approved according to the DB standard RIL 910
- For internal and external cleaning of vehicles and buildings
- Ready-to-use

Note

Test material compatibility on an inconspicuous area prior to initial use.

All information contained in our brochures is accurate to the best of our knowledge and experience. No liability can be derived from the information herein. For details about the product, please refer to the safety data sheet.

3 0419



Taunusstraße 19 · 80807 Munich Tel. +49 89 3506080 info@dr-schnell.com www.dr-schnell.com

